FITTING INSTRUCTIONS FOR WHEEL SPACERS & SHIMS

Thank you for choosing PCD Parts.

Your new spacers/shims are easy to fit at home in just 8 simple steps providing you have the right tools.

NEVER USE AN IMPACT SOCKET GUN. ALWAYS USE HAND TOOLS.

Before you start:

- Check all bolts are the same length
- Check that you have the correct bolt seat for your wheels.
- Measure the hub spigot lengths 10mm, 12mm & 15mm
 wheel spacers do not fit all vehicles.
- STEP 1: Simply unbolt your wheel and remove.
- STEP 2: Wire brush and wipe the bore and wheel hub clean (it must be dirt and rust free.)
- STEP 3: Apply a little copper grease (or similar) to stop the faces sticking together.
- STEP 4: Slide the spacer onto the vehicle's hub.
- STEP 5: Check that the spacer is sitting flush/flat against the hub with no visible gap or rocking movement.

IF THEY ARE NOT SITTING FLUSH, REMOVE THE SPACERS. DO NOT MOUNT THE WHEEL.

- STEP 6: Gently position the wheel onto the spacer spigot, taking care not to damage the machined surface.
- STEP 7: Secure the wheel with the extended wheel bolts and torque them to the required specification.
- STEP 8: While the vehicle is still jacked up, rotate the wheels to check that each wheel is rotating freely and not catching.

WE DO NOT REFUND ANY SPACERS THAT HAVE BEEN DAMAGED DURING FITTING.